

G. HOISTING THE SAIL

- 1) Attach the clew of the sail to the hook fastened to the rod on the end of the boom.
- 2) Hoist the sail with the halyard until the wire tail passes through the halyard latch. Holding the halyard aft, let the sail down until the metal sleeve on the wire tail hooks into the halyard latch. To lower the sail, hold the halyard close to the mast, pull the sail up until the tail unhooks and then lower by pulling the sail down.

CAUTIONS

- A. Keep vent hole in forward end of the cockpit tub clear to insure equalization of hull pressure.
- B. Release outhaul hook when boat is beached or docked.
- C. Flush all moving parts with fresh water after use.
- D. When trailering or car-topping, make certain the hull is well-supported. Distribute load on large, well-fitted, padded bunks.
- E. Make sure the drain mounted on the starboard deck is closed while sailing.
- F. Your Super Sunfish sailboat is designed and built for use in protected waters. It should not be used in conditions where high wind and/or heavy seas prevail.
- G. You should always wear a coast guard approved flotation device while sailing your boat.

©Super Sunfish is a registered trademark of AMF Incorporated.
©AMF Incorporated 1980
Printed in USA 12f79

AMF Alcort Sailboats, South Leonard Street, Waterbury, Conn. 06708 * Tel: 203/756-7091